



## Cadet

by designer Troels Bøgely

Model: GVC-10  
Material: glass fibre reinforced plastic (GFP)  
Installation: vertical

### Installation of the uridan water free urinals is very simple.

If you retrofitting existing flushing urinals with uridan waterless urinals, please ensure that the sewer line is jetted and clean of uric scale before installation.

The uridan urinals work without water, and therefore should only be connected with  $\varnothing$  50 mm drainpipes. Installation should be carried out by authorized plumbers.

1. Take height from the floor and mark holes with fitting No. (4). Drill holes and mount fitting No. (4).
2. Mount the wastewater pipes using the sketch. Make sure the distance from the wall to center of the pipe is around 107 mm.
3. Hold the urinal against the wall and push firmly onto the fitting No. (4). Thus, the pipe connection is made.
4. Fill the waste trap Pos. (B) full with water.
5. Insert the stainless steel cover Pos. (A).
6. Pour 1 bottle uriLOCK (0,3 liter) over the cover.
7. Seal the gap between the wall and the urinal with silicone.
8. The uridan-urinal is now ready for use!

**Please leave care booklet, cleaning and maintenance instructions and suction device with costumer.**

