



Cadet

by designer Troels Bøgely

Model: KHC-10
Material: cermaic
Installation: horizontal

Installation of the uridan water free urinals is very simple.

If you retrofitting existing flushing urinals with uridan waterless urinals, please ensure that the sewer line is jetted and clean of uric scale before installation.

The uridan urinals work without water, and therefore should only be connected with \varnothing 50 mm drainpipes. Installation should be carried out by authorized plumbers.

1. Take the height from the center of the waste pipe and mark the holes for both special screws No. (19). Drill holes and mount screws.
2. Install the 87 ° bend, keeping the distance of 100 mm from the wall to the middle of the pipe. The pipe connection is now established.
3. Adjust fitting No. (15), mark holes, drill holes and mount fitting No. (15)
4. Hold the urinal against the wall and push firmly onto the fitting No. (4). Thus, the pipe connection is made.
Please note: Between urinal and wall should be a gap of approx. 2 to 5 mm, so that tension cracks can be prevented.
5. Fill the waste trap Pos. (B) full with water.
6. Insert the stainless steel cover Pos. (A).
7. Pour 1 bottle uriLOCK (0,3 liter) over the cover.
8. Seal the gap between the wall and the urinal with silicone.
9. The uridan urinal is now ready for use!

Please leave customer care booklet, cleaning and maintenance instructions and suction device with customer.

