



Captain

by designer Yu Bobek

Model: GX-10
Material: glass fibre reinforced plastic (GFP)
Installation: vertical

Installation of the uridan water free urinals is very simple.

If you retrofitting existing flushing urinals with uridan waterless urinals, please ensure that the sewer line is jetted and clean of uric scale before installation.

The uridan urinals work without water, and therefore should only be connected with \varnothing 50 mm drainpipes. Installation should be carried out by authorized plumbers.

1. Mark holes for fittings No. (20) and install them.
2. Hold the urinal against the wall and push firmly onto the fitting No. (20). Slide the urinal down to the waste outlet (\varnothing 50 mm).
3. Fill the waste trap Pos. (B) full with water.
4. Insert the stainless steel cover Pos. (A).
5. Pour 1 bottle uriLOCK (0,3 liter) over the cover.
6. Apply silicon sealant around the edge of the urinal - between urinal and wall & floor.
7. The uridan urinal is now ready for use!

Please leave customer care booklet, cleaning and maintenance instructions and suction device with customer.

