

Crew - Length 120 cm

by designer uridan a/s



Model: GR1200-10
Material: glass fibre reinforced plastic (GFP)
Installation: horizontal oder vertical

Installation of the uridan water free urinals is very simple.

If you retrofitting existing flushing urinals with uridan waterless urinals, please ensure that the sewer line is jetted and clean of uric scale before installation.

The uridan urinals work without water, and therefore should only be connected with \varnothing 50 mm drainpipes. Installation should be carried out by authorized plumbers.

1. Mark holes for fittings No. (8) and install them.
2. Hold the urinal against the wall and press firmly onto the fittings no. (8) and the waste pipe.
3. Install screen Pos. (C) by using the included screws.
3. Fill the waste trap Pos. (B) with water.
4. Insert the stainless steel cover Pos. (A).
5. Pour 1 bottle uriLOCK (0,3 liter) over the cover.
6. Apply silicon sealant between urinal and wall.
7. The uridan urinal is now ready for use!

Please leave customer care booklet, cleaning and maintenance instructions and suction device with customer.

