

uridan-Cleaning Instructions

Daily Cleaning



uridans **uriCLEAN** NEU



- » Spray **uriCLEAN** on the cover and surface.
- » Leave for a moment to react.



- » Clean by brushing circularly with a conventional brush.



- » Polish the outer and inner surface in circular motions with the **uriCLOTH** cleaning cloth.

Refilling

around every 3 months necessary



uridans **uriLOCK** NEU



- » Pour **uriLOCK** blocking fluid directly over the cover.

**NOW IN ONLY
10 SECONDS!**

uridan-Cleaning Instructions

Deep Cleaner

1 to 2 times a year recommended



uriSTRONG



- » Pour 5 to 10 liters of water directly over the cover
- » Lift cover with suction device.



- » Mix warm water with **uriSTRONG** as indicated in the instruction.



- » Pour the **uriSTRONG-Mix** into the urinal with an exposure time of 5 to 30 min.



- » Rinse 10 liters of cold water.



- » Insert the cover and pour **uriLOCK** over the cover.